

# IMPORTANT NOTICE!!!

**Fan to Crankshaft: Torque should be set between the ranges of 57 Ft-lbs (min.) and 63 Ft-lbs (max.).**

The fan to crankshaft torque numbers mentioned above replace the current numbers listed in the "Torque Specifications" tables in the following manuals and affects the following blower models:

<b>Operators</b>			
<b>Manual P/N</b>	<b>Page #</b>	<b>Model #</b>	<b>Description</b>
4166749	14	9390-02-01	Little Wonder Optimax Blower 390cc, Honda GX390
4166749	14	9400-03-01	Little Wonder Optimax Blower 400cc, Subaru EX400
4166799	19	9390-12-01	Little Wonder Optimax Blower 390cc, Honda GX390 SP
4166799	19	9400-13-01	Little Wonder Optimax Blower 400cc, Subaru EX400 SP